## <u>YEAR 2019 SPEEDPLAY ROAD SHOE COMPATIBILITY GUIDE\*\*</u> <u>ZERO, ZERO AERO, ZERO PAVÉ, ULTRA LIGHT ACTION OR LIGHT ACTION PEDALS WITH</u> <u>WALKABLE CLEATS</u>

	MALABLE OLLATS
ning Screws supplie	d with Zero Aero or Ultra Light Action Walkable Cleats. Do NOT use previous versions of Cleat Fastening
	I previous versions of Cleat Fastening Screws are not compatible with Zero Aero or Ultra Light Action Walkable
	stem which can lead to a fall that can result in severe injury. Never install cleats using any combination of new
URVATURES MAY RE	used parts with Walkable Cleat parts. EQUIRE SNAP SHIMS OTHER THAN THOSE RECOMMENDED BELOW. PLEASE VISIT OUR WEBSITE AT
	OUR CLEAT INSTALLATION VIDEO UNDER TECH SUPPORT / VIDEO LIBRARY. IPATIBLE WITH FACTORY-INSTALLED 5-F AND 5-R SNAP SHIMS
	// Bontrager Silver Series Carbon // Crono CR - 1 CR - 3 // Exustar // FLR // Lake
	Mavic // Nalini Carbon // Scott Nylon // Spiuk Carbon // Suplest
	ON-STANDARD 2019 MODEL SHOES AND PRIOR YEAR MODEL SHOES
Current year & earlier	Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Current year & earlier	* Remove 5-F & 5-R Snap-Shims. Install 6-F & 6-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
	Use 5-F & 5-R Snap-Shims.
	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
Current year &	* Remove 5-F & 5-R Snap-Shims. Install 6-F & 6-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Current year &	* Remove 5-F & 5-R Snap-Shims. Install 6-F & 6-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw
earlier Current year &	of each V.2 Base Plate. Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2
earlier	Base Plate. * Remove 5-F & 5-R Snap-Shims. Install 6-F & 6-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw
earlier	of each V.2 Base Plate.
Current year & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
Current year & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
2012 - 2019	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
	Use 5-F & 5-R Snap-Shims.
	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims. May require "Extra Shim" under
earlier	cleat-mounting screw of each V.2 Base Plate.
Current year & earlier	Use 5-F & 5-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
2019 & earlier	Use 5-F & 5-R Snap-Shims.
2009 - 2019	Use 5-F & 5-R Snap-Shims.
Current year & earlier	Omit V.2 Base Plate. Requires Northwave-supplied kit: NW Speedplay adaptor (Available through Northwave).
Current year &	Omit V.2 Base Plate. Use Northwave-supplied Time/Speedplay insert. Requires 4x9.5mm Walkable Cleat Fastening Screws (Part #14145) available from Speedplay.
	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
	Use 5-F & 5-R Snap-Shims.
	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims. May require "Extra Shim" under cleat-mounting screw
2016	of each V.2 Base Plate.
	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
	Use 5-F & 5-R Snap-Shims.
2010 - 2019	* Remove 5-F & 5-R Snap-Shims. Install 6-F & 6-R Snap-Shims.
2019 & earlier	Use 5-F & 5-R Snap-Shims.
2019 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
2009 - through - 2012	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each V.2 Base Plate.
2011 - 2019	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap Shims.
2012 & earlier	* Remove 5-F & 5-R Snap Shims. Install 6-F & 6-R Snap-Shims.
uts remain in the V	
	ole cleat pattern (Speedplay V.2 Base Plate not used).
	Omit V.2 Base Plate. See note below regarding 4-Hole Carbon Fiber Soles.
/ Riivo / Pinnacle Racing For Shoes and Years not listed, Please call Speedplay for assistance.	
4-Hole Shoe Soles: Must use the Walkable Cleat Protector Shim Kit (Part #14135), sold separately and available from Speedplay, to prevent contact between the pedal body and the	
	bus wear damage to the shoe sole and the cleat will result.
at mounting screws	with any previous models of Speedplay X cleats including the Slim Line Cleat. The Snap-Shim Cleat mounting
ough the older base	plates. This may cause the cleat to pull off the shoe causing a fall that may result in severe injury.
	n Walkable Cleats. All ention of the pedal sys cing cleats, replace <u>all</u> URVATURES MAY RI DPLAY.COM TO SEE DDEL SHOES COM le // Bontrager Nylon REQUIRED FOR NY Current year & earlier 2019 & earlier 2019 & earlier 2019 & earlier Current year & earlier Current year & earlier Current year & earlier Current year & earlier 2012 - 2019 2011 & earlier 2019 & earlier Current year & earlier Current year & earlier 2019 & earlier 2019 & earlier